

Incluye asas de silicona
Includes silicone handles



Cacerola con tapa

Faitout avec couvercle
Bratentopf mit Deckel
Casserole with lid
Caçarola com tampa

Ref	€	Ø (cm)	h (cm)	L	U.Venta
27520	47,50	20	9,5	2,60	1
27524	57,40	24	11,0	4,40	1
27528	69,90	28	12,0	6,60	1



Cazo Recto

Casserole
Stielkasserolle, flach
Saucepan
Caçarola direita



Ref	€	Ø (cm)	h (cm)	L	U.Venta
27516	27,50	16	8,0	1,35	1

Incluye asas de silicona
Includes silicone handles



Tartera con tapa

Plat rond avec couvercle
Pfanne mit Deckel
Round dish with lid
Tarteira com tampa

Ref	€	Ø (cm)	h (cm)	L	U.Venta
27728	65,40	28	7,5	4,10	1
27732	78,40	32	8,0	5,70	1
27736	92,40	36	8,0	7,30	1



Sartén

Poêle
Pfanne
Frying-pan
Sertã



Ref	€	Ø (cm)	h (cm)	U.Venta
27820	28,80	20	5,0	6
27824	35,50	24	5,5	4
27828	43,10	28	6,0	6



Grill

Grill
Grill Induktionfähig
Grill
Grelhador



Ref	€	cm	h (cm)	U.Venta
27827	50,10	28x28	4,0	1



Sartén 4 cavidades

Poêle 4 cavités
Pfanne, 4-fache Einteilung
Frying-pan 4 cavities
Sertã 4 cavidades



Ref	€	cm	h (cm)	U.Venta
27832	43,30	32x26	3,5	1



Aro protector de silicona
Silicone protective ring



Tapa de cristal

Couvercle en verre
Glasdeckel
Glass lid
Tampa de vidro

Ref	€	Ø (cm)	U.Venta
27420	9,80	20	1
27424	11,40	24	1
27428	13,10	28	1
27432	14,90	32	1
27436	16,60	36	1



Asas para batería TITANIUM

Poignées
Griffchutz, Silikon
Handles
Asas



Ref	€	Ø (cm)	U.Venta
R27520A	4,00	20	1
R27528A	4,10	24-28	1
R27732A	5,20	32-36	1